

## EF 109L/19 K V Cat. 2025 Garden tractor



### Документы

Mulching Kit

Mowing deck

Engine

Tank

Transmission

Frame

Front axle

Steering arm

Rear axle

Seat

Cutting plate lifting

Electrical parts

body


Towing hitch

[www.agrodialog.ru](http://www.agrodialog.ru)




| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|-------|----------|
| 3      | 2   | TS000043R   | Hook        |               |               |       |          |
| 4      | 2   | TS000044R   | Tie rod     |               |               |       |          |
| 6      | 1   | TS000046R   | Deflector   |               |               |       |          |

www.agrodialog.ru



## изображение Mowing deck


| Ref.Nu | Qty | Part number | Description            | Validity from | Validity till | Notes                                                                     | Bulletin |
|--------|-----|-------------|------------------------|---------------|---------------|---------------------------------------------------------------------------|----------|
| 1      | 1   | TS000115R   | Right guard            |               |               |                                                                           |          |
| 4      | 5   | TS000066R   | Clamp                  |               |               |                                                                           |          |
| 7      | 1   | TS000116R   | Pin                    |               |               |                                                                           |          |
| 8      | 1   | TS000117R   | Spring                 |               |               |                                                                           |          |
| 9      | 2   | TS000071R   | Screw                  |               |               |                                                                           |          |
| 10     | 2   | TS000074R   | Wheel                  |               |               |                                                                           |          |
| 12     | 1   | TS000118R   | Mount                  |               |               |                                                                           |          |
| 14     | 1   | TS000119R   | Belt cover             |               |               |                                                                           |          |
| 15     | 1   | TS000143R   | V belt                 |               |               |                                                                           |          |
| 16     | 1   | TS000420R   | Bracket                |               |               |                                                                           |          |
| 18     | 1   | TS000421R   | Rod                    |               |               |                                                                           |          |
| 19     | 2   | TS000090R   | Water hose connection  |               |               |                                                                           |          |
| 21     | 1   | TS000422R   | Spacer                 |               |               |                                                                           |          |
| 23     | 1   | TS000423R   | Lever                  |               |               |                                                                           |          |
| 26     | 1   | TS000122R   | Bushing                |               |               |                                                                           |          |
| 27     | 1   | TS000126R   | Pulley                 |               |               |                                                                           |          |
| 29     | 1   | TS000125R   | Guard sx               |               |               |                                                                           |          |
| 30     | 1   | TS000424R   | Shaft                  |               |               |                                                                           |          |
| 32     | 1   | TS000128R   | Belt cover             |               |               |                                                                           |          |
| 33     | 1   | TS000130R   | Spring                 |               |               |                                                                           |          |
| 34     | 1   | TS000065R   | Screw                  |               |               |                                                                           |          |
| 36     | 1   | TS000427R   | Mowing deck            |               |               |                                                                           |          |
| 39     | 1   | TS000145R   | Bracket                |               |               |                                                                           |          |
| 40     | 2   | TS000132R   | Nut                    |               |               |                                                                           |          |
| 41     | 2   | TS000111R   | Pulley                 |               |               |                                                                           |          |
| 42     | 2   | TS000082R   | Key                    |               |               |                                                                           |          |
| 43     | 2   | TS000133R   | Blade shaft            |               |               |                                                                           |          |
| 44     | 2   | TS000085R   | Disc (guard)           |               |               |                                                                           |          |
| 45     | 4   | TS000086R   | Thrust bearing         |               |               |                                                                           |          |
| 46     | 2   | TS000134R   | Support                |               |               |                                                                           |          |
| 48     | 2   | TS000135R   | Guard                  |               |               |                                                                           |          |
| 49     | 2   | TS000099R   | Key                    |               |               |                                                                           |          |
| 50     | 2   | TS000095R   | Blade hub              |               |               | Acquistare anche il codice<br>TS000135R / Also purchase<br>code TS000135R |          |
| 51     | 2   | TS000136R   | Pin                    |               |               |                                                                           |          |
| 53     | 2   | TS000426R   | Plate                  |               |               |                                                                           |          |
| 55     | 2   | TS000146R   | Blade                  |               |               |                                                                           |          |
| 57     | 2   | TS000097R   | Washer                 |               |               |                                                                           |          |
| 58     | 2   | TS000098R   | Screw                  |               |               |                                                                           |          |
| 61     | 1   | TS000138R   | Pin                    |               |               |                                                                           |          |
| 62     | 1   | TS000139R   | Spring                 |               |               |                                                                           |          |
| 63     | 1   | TS000140R   | Locking lever          |               |               |                                                                           |          |
| 64     | 1   | TS000141R   | Lever support          |               |               |                                                                           |          |
| 65     | 1   | TS000142R   | Deflector              |               |               |                                                                           |          |
| 66     | 1   | TS000429R   | Cutting plate assembly |               |               | Senza cinghie e protezioni /<br>Without belts and<br>protections          |          |



изображение Engine


| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes                     | Bulletin |
|--------|-----|-------------|----------------|---------------|---------------|---------------------------|----------|
| 1      | 1   | TS000147R   | Knob           |               |               |                           |          |
| 4      | 1   | TS000430R   | Throttle cable |               |               |                           |          |
| 7      | 1   | TS000009R   | Key            |               |               |                           |          |
| 8      | 1   | TS000159R   | Pulley         |               |               | Motore 14,5 K / 16 K / 19 |          |
| 10     | 1   | TS000010R   | Support        |               |               |                           |          |
| 12     | 1   | TS000149R   | Clutch         |               |               |                           |          |
| 13     | 1   | TS000150R   | Bushing        |               |               |                           |          |
| 14     | 1   | TS000151R   | Thickness      |               |               |                           |          |
| 15     | 1   | TS000152R   | Bolt           |               |               |                           |          |
| 16     | 1   | TS000153R   | Plate          |               |               |                           |          |
| 18     | 1   | TS000436R   | Bracket        |               |               |                           |          |
| 23     | 1   | TS000431R   | Muffler        |               |               | Motore 14,5 K / 16 K /19  |          |
| 24     | 2   | TS000156R   | Gasket         |               |               |                           |          |
| 25     | 1   | TS000432R   | Grid           |               |               |                           |          |
| 29     | 1   | TS000158R   | Support        |               |               |                           |          |

www.agrodialog.ru



| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|-------|----------|
| 10     | 1   | TS000012R   | Filter      |               |               |       |          |
| 11     | 1   | TS000161R   | Tank        |               |               |       |          |
| 13     | 2   | TS000162R   | Band        |               |               |       |          |
| 14     | 1   | TS000163R   | Fuel hose   |               |               |       |          |
| 16     | 1   | TS000013R   | Tank cap    |               |               |       |          |


www.agrodialog.ru



## изображение Transmission

| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|----------------|---------------|---------------|-------|----------|
| 2      | 2   | TS000173R   | Bushing        |               |               |       |          |
| 3      | 1   | TS000253R   | Spacer         |               |               |       |          |
| 5      | 1   | TS000255R   | Support        |               |               |       |          |
| 6      | 1   | TS000130R   | Spring         |               |               |       |          |
| 8      | 1   | TS000122R   | Bushing        |               |               |       |          |
| 9      | 1   | TS000007R   | Pulley         |               |               |       |          |
| 11     | 1   | TS000006R   | Pulley         |               |               |       |          |
| 12     | 1   | TS000005R   | Thrust bearing |               |               |       |          |
| 16     | 1   | TS000263R   | Plate          |               |               |       |          |
| 20     | 1   | TS000259R   | Screw          |               |               |       |          |
| 21     | 1   | TS000025R   | Belt           |               |               |       |          |
| 23     | 3   | TS000023R   | Pulley         |               |               |       |          |
| 24     | 2   | TS000260R   | Bushing        |               |               |       |          |
| 27     | 1   | TS000264R   | Guide pulley   |               |               |       |          |

www.agrodialog.ru




www.agrodialog.ru

## изображение Frame

| Ref.Nu | Qty | Part number | Description             | Validity from | Validity till | Notes          | Bulletin |
|--------|-----|-------------|-------------------------|---------------|---------------|----------------|----------|
| 2      | 1   | TS000165R   | Right footboard support |               |               |                |          |
| 4      | 1   | TS000166R   | Footrest pad            |               |               | Destra; Right  |          |
| 5      | 1   | TS000167R   | Right footboard cover   |               |               |                |          |
| 8      | 1   | TS000168R   | Right footboard support |               |               | Sinistra; Left |          |
| 10     | 2   | TS000169R   | Bushing                 |               |               |                |          |
| 12     | 1   | TS000170R   | Frame                   |               |               |                |          |
| 13     | 1   | TS000171R   | Hood support            |               |               | Sinistra; Left |          |
| 14     | 1   | TS000172R   | Support                 |               |               |                |          |
| 15     | 4   | TS000014R   | Washer                  |               |               |                |          |
| 16     | 1   | TS000015R   | Bumper                  |               |               |                |          |
| 17     | 4   | TS000173R   | Bushing                 |               |               | Destra; Right  |          |
| 18     | 1   | TS000016R   | Bumper                  |               |               |                |          |
| 19     | 1   | TS000017R   | Lower hood              |               |               |                |          |
| 22     | 1   | TS000174R   | Hood support            |               |               |                |          |
| 23     | 1   | TS000175R   | Support                 |               |               |                |          |
| 25     | 2   | TS000176R   | Plate                   |               |               |                |          |
| 26     | 1   | TS000177R   | Column support          |               |               |                |          |
| 28     | 1   | TS000178R   | Left footboard support  |               |               |                |          |
| 29     | 1   | TS000179R   | Footrest pad            |               |               |                |          |
| 30     | 1   | TS000180R   | Left footboard cover    |               |               |                |          |
| 31     | 1   | TS000181R   | Frame                   |               |               |                |          |
| 32     | 2   | TS000182R   | Support                 |               |               |                |          |
| 33     | 1   | TS000183R   | Left footboard support  |               |               |                |          |

www.agrodialog.ru




www.agrodialog.ru

изображение Front axle

| Ref.Nu | Qty | Part number | Description        | Validity from | Validity till | Notes          | Bulletin |
|--------|-----|-------------|--------------------|---------------|---------------|----------------|----------|
| 1      | 2   | TS000198R   | Hub cap            |               |               |                |          |
| 3      | 2   | TS000199R   | Washer             |               |               |                |          |
| 4      | 4   | TS000200R   | Spacer             |               |               |                |          |
| 5      | 2   | TS000018R   | Compl. front wheel |               |               |                |          |
| 5.4    | 4   | TS000204R   | Thrust bearing     |               |               |                |          |
| 6      | 1   | TS000019R   | Pin                |               |               | Destro; Right  |          |
| 8      | 4   | TS000020R   | Bushing            |               |               |                |          |
| 9      | 1   | TS000205R   | Front axle         |               |               |                |          |
| 11     | 1   | TS000021R   | Lever              |               |               |                |          |
| 17     | 1   | TS000206R   | Spacer             |               |               |                |          |
| 18     | 2   | TS000068R   | Nipple             |               |               |                |          |
| 21     | 1   | TS000022R   | Pin                |               |               | Sinistro; Left |          |


www.agrodialog.ru



[www.agrodialog.ru](http://www.agrodialog.ru)

## изображение Steering arm


| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes       | Bulletin |
|--------|-----|-------------|----------------|---------------|---------------|-------------|----------|
| 1      | 1   | TS000267R   | Joint          |               |               |             |          |
| 3      | 1   | TS000268R   | Tie rod        |               |               |             |          |
| 5      | 1   | TS000269R   | Plate          |               |               |             |          |
| 8      | 1   | TS000270R   | Sleeve         |               |               |             |          |
| 9      | 1   | TS000271R   | Bushing        |               |               |             |          |
| 10     | 1   | TS000272R   | Snap ring      |               |               |             |          |
| 11     | 1   | TS000273R   | Steering arm   |               |               |             |          |
| 13     | 2   | TS000274R   | Bushing        |               |               |             |          |
| 14     | 1   | TS000275R   | Tie rod        |               |               |             |          |
| 16     | 1   | TS000026R   | Sprocket       |               |               |             |          |
| 17     | 1   | TS000276R   | Pin            |               |               |             |          |
| 19     | 1   | TS000378R   | Bushing        |               |               |             |          |
| 20     | 1   | TS000277R   | Bushing        |               |               |             |          |
| 21     | 1   | TS000278R   | Cotter pin     |               |               |             |          |
| 22     | 1   | TS000279R   | Fixing plate   |               |               |             |          |
| 23     | 2   | TS000280R   | Bushing        |               |               |             |          |
| 24     | 1   | TS000027R   | Sector         |               |               |             |          |
| 25     | 1   | TS000281R   | Fixing plate   |               |               |             |          |
| 26     | 1   | TS000282R   | Joint          |               |               |             |          |
| 28     | 1   | TS000283R   | Spacer         |               |               |             |          |
| 30     | 1   | TS000284R   | Steering wheel |               |               |             |          |
| 31     | 1   | TS000028R   | Support        |               |               |             |          |
| 32     | 1   | TS000379R   | Washer         |               |               |             |          |
| 33     | 1   | TS000375R   | Cover          |               |               | Rosso - Red |          |



www.agrodialog.ru

изображение Rear axle


| Ref.Nu | Qty | Part number | Description       | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------------|---------------|---------------|-------|----------|
| 1      | 2   | TS000198R   | Hub cap           |               |               |       |          |
| 2      | 2   | TS000207R   | Snap ring         |               |               |       |          |
| 3      | 4   | TS000199R   | Washer            |               |               |       |          |
| 4      | 2   | TS000212R   | Compl. rear wheel |               |               |       |          |
| 5      | 2   | TS000210R   | Key               |               |               |       |          |
| 8      | 1   | TS000240R   | Plate             |               |               |       |          |
| 10     | 1   | TS000241R   | Transmission      |               |               |       |          |
| 11     | 1   | TS000242R   | Pin               |               |               |       |          |
| 15     | 1   | TS000243R   | Support           |               |               |       |          |
| 17     | 1   | TS000244R   | Break cable       |               |               |       |          |
| 18     | 1   | TS000245R   | Clamp cover rear  |               |               |       |          |
| 19     | 1   | TS000246R   | Pedal             |               |               |       |          |
| 23     | 1   | TS000247R   | Pin               |               |               |       |          |
| 25     | 1   | TS000248R   | Tie rod           |               |               |       |          |
| 27     | 1   | TS000249R   | Fixing plate      |               |               |       |          |
| 29     | 1   | TS000250R   | Spring            |               |               |       |          |
| 30     | 2   | TS000231R   | Support           |               |               |       |          |
| 32     | 1   | TS000230R   | Support           |               |               |       |          |
| 33     | 1   | TS000251R   | Clamp cover front |               |               |       |          |
| 37     | 1   | TS000232R   | Bushing           |               |               |       |          |
| 38     | 1   | TS000233R   | Compl.brake lever |               |               |       |          |
| 40     | 1   | TS000234R   | Control rod       |               |               |       |          |
| 41     | 1   | TS000235R   | Handle            |               |               |       |          |
| 42     | 1   | TS000236R   | Fork              |               |               |       |          |
| 43     | 1   | TS000237R   | Spring            |               |               |       |          |
| 44     | 1   | TS000439R   | Brake pedal       |               |               |       |          |
| 45     | 1   | TS000239R   | Cover moulding    |               |               |       |          |



## изображение Seat

| Ref.Nu | Qty | Part number | Description  | Validity from | Validity till | Notes       | Bulletin |
|--------|-----|-------------|--------------|---------------|---------------|-------------|----------|
| 2      | 1   | TS000285R   | Bar          |               |               |             |          |
| 4      | 2   | TS000286R   | Spring       |               |               |             |          |
| 7      | 2   | TS000287R   | Cover        |               |               |             |          |
| 8      | 1   | TS000418R   | Seat support |               |               |             |          |
| 9      | 2   | TS000289R   | Screw        |               |               |             |          |
| 10     | 2   | TS000290R   | Slide        |               |               |             |          |
| 12     | 1   | TS000029R   | Seat switch  |               |               |             |          |
| 13     | 1   | TS000372R   | Seat         |               |               | Rosso - Red |          |
| 14     | 4   | TS000291R   | Spacer       |               |               |             |          |

www.agrodialog.ru



www.agrodialog.ru

## изображение Cutting plate lifting


| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|-------|----------|
| 3      | 2   | TS000444R   | Rod         |               |               |       |          |
| 4      | 1   | TS000293R   | Tie rod     |               |               |       |          |
| 6      | 1   | TS000294R   | Joint       |               |               |       |          |
| 10     | 1   | TS000308R   | Rod         |               |               |       |          |
| 11     | 1   | TS000309R   | Axel lift   |               |               |       |          |
| 12     | 1   | TS000297R   | Rod         |               |               |       |          |
| 13     | 1   | TS000298R   | Support     |               |               |       |          |
| 15     | 4   | TS000231R   | Support     |               |               |       |          |
| 16     | 3   | TS000299R   | Joint       |               |               |       |          |
| 17     | 1   | TS000310R   | Lever       |               |               |       |          |
| 19     | 1   | TS000301R   | Plate       |               |               |       |          |
| 20     | 1   | TS000226R   | Knob        |               |               |       |          |
| 21     | 1   | TS000030R   | Support     |               |               |       |          |
| 22     | 1   | TS000302R   | Spring      |               |               |       |          |
| 25     | 1   | TS000303R   | Spring      |               |               |       |          |
| 26     | 1   | TS000031R   | Lever       |               |               |       |          |
| 27     | 1   | TS000223R   | Snap ring   |               |               |       |          |
| 28     | 2   | TS000378R   | Bushing     |               |               |       |          |
| 29     | 1   | TS000304R   | Lever       |               |               |       |          |
| 30     | 1   | TS000311R   | Tie rod     |               |               |       |          |
| 31     | 1   | TS000312R   | Tie rod     |               |               |       |          |

www.agrodialog.ru



## изображение Electrical parts

| Ref.Nu | Qty | Part number | Description          | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|----------------------|---------------|---------------|-------|----------|
| 1      | 1   | TS000314R   | Battery cables       |               |               |       |          |
| 2      | 1   | TS000447R   | Wiring               |               |               |       |          |
| 3      | 20  | TS000316R   | Band                 |               |               |       |          |
| 3      | 5   | TS000317R   | Band                 |               |               |       |          |
| 4      | 1   | TS000319R   | Battery cables       |               |               |       |          |
| 5      | 1   | TS000032R   | Switch               |               |               |       |          |
| 7      | 1   | TS000033R   | Solenoid             |               |               |       |          |
| 10     | 1   | TS000323R   | Clamp                |               |               |       |          |
| 12     | 1   | TS000324R   | Wire                 |               |               |       |          |
| 13     | 1   | TS000325R   | Fuse                 |               |               |       |          |
| 14     | 1   | TS000034R   | Switch               |               |               |       |          |
| 15     | 1   | TS000326R   | Switch               |               |               |       |          |
| 16     | 1   | TS000035R   | Shoe                 |               |               |       |          |
| 18     | 1   | TS000332R   | Belt                 |               |               |       |          |
| 19     | 1   | TS000038R   | Battery              |               |               |       |          |
| 20     | 2   | TS000333R   | Bracket              |               |               |       |          |
| 22     | 1   | TS000336R   | Control lever        |               |               |       |          |
| 23     | 1   | TS000037R   | Micro-switch         |               |               |       |          |
| 24     | 1   | TS000435R   | Switch               |               |               |       |          |
| 25     | 1   | TS000337R   | Bracket              |               |               |       |          |
| 29     | 1   | 68050054    | Support + switch kit |               |               |       |          |
| 32     | 1   | 68130481    | Battery charger      |               |               |       |          |
| 33     | 1   | TS000318R   | Switch protection    |               |               |       |          |
| 34     | 1   | TS000412R   | Starting key         |               |               |       |          |




www.agrodialog.ru

изображение body

| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes       | Bulletin |
|--------|-----|-------------|----------------|---------------|---------------|-------------|----------|
| 1      | 1   | TS000340R   | Wiring         |               |               |             |          |
| 2      | 1   | TS000341R   | Adapter        |               |               |             |          |
| 3      | 1   | TS000342R   | Deflector      |               |               |             |          |
| 4      | 1   | TS000343R   | Right guard    |               |               |             |          |
| 6      | 5   | TS000344R   | Fairled        |               |               |             |          |
| 7      | 1   | TS000360R   | Right guard    |               |               | Rosso - Red |          |
| 10     | 2   | TS000345R   | Pin            |               |               |             |          |
| 11     | 1   | TS000441R   | Headlamp       |               |               |             |          |
| 12     | 1   | TS000363R   | Guard          |               |               | Rosso - Red |          |
| 13     | 1   | TS000039R   | Upper hood     |               |               |             |          |
| 14     | 1   | TS000442R   | Headlamp       |               |               |             |          |
| 15     | 1   | TS000366R   | Engine cover   |               |               | Rosso - Red |          |
| 16     | 1   | TS000369R   | Left guard     |               |               | Rosso - Red |          |
| 17     | 1   | TS000348R   | Left guard     |               |               |             |          |
| 19     | 1   | TS000349R   | Cover          |               |               |             |          |
| 20     | 4   | TS000350R   | Shock absorber |               |               |             |          |
| 22     | 1   | TS000351R   | Dashboard      |               |               |             |          |
| 23     | 9   | TS000066R   | Clamp          |               |               |             |          |
| 24     | 1   | TS000352R   | Panel          |               |               |             |          |
| 25     | 1   | TS000040R   | Cover          |               |               |             |          |
| 29     | 1   | TS000042R   | Cover          |               |               |             |          |
| 30     | 1   | TS000356R   | Guard          |               |               |             |          |
| 31     | 2   | TS000173R   | Bushing        |               |               |             |          |
| 34     | 1   | TS000357R   | Lock           |               |               |             |          |

www.agrodialog.ru



[www.agrodialog.ru](http://www.agrodialog.ru)

| Ref.Nu | Qty | Part number | Description  | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|--------------|---------------|---------------|-------|----------|
| 2      | 1   | TS000358R   | Towing hitch |               |               |       |          |
| 3      | 2   | TS000359R   | Spacer       |               |               |       |          |

www.agrodialog.ru