

## EF 86R/14,5 K Cat. 2024 Garden tractor



### Документы

Mulching Kit

Grassbag

Mowing deck

Engine

Tank

Transmission

Frame

Front axle

Steering arm

Rear axle

Seat

Cutting plate lifting

Electrical parts

body


Towing hitch

Labels

Starter, carburettor and air filter

Engine assy

www.agrodialog.ru




www.agrodialog.ru

изображение Mulching Kit

| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|-------|----------|
| 1      | 1   | TS000047R   | Knob        |               |               |       |          |
| 2      | 2   | TS000048R   | Spring      |               |               |       |          |
| 3      | 1   | TS000049R   | Handle      |               |               |       |          |
| 4      | 1   | TS000050R   | Spring      |               |               |       |          |
| 5      | 1   | TS000051R   | Pin         |               |               |       |          |
| 6      | 1   | TS000001R   | Deflector   |               |               |       |          |


www.agrodialog.ru



изображение Grassbag


| Ref.Nu | Qty | Part number | Description     | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-----------------|---------------|---------------|-------|----------|
| 2      | 1   | TS000052R   | Exhaust         |               |               |       |          |
| 5      | 1   | TS000053R   | Exhaust pipe    |               |               |       |          |
| 6      | 2   | TS000054R   | Screw           |               |               |       |          |
| 7      | 1   | TS000055R   | Cap             |               |               |       |          |
| 9      | 1   | TS000056R   | Knob            |               |               |       |          |
| 10     | 1   | TS000057R   | Lever           |               |               |       |          |
| 11     | 1   | TS000058R   | Gasket          |               |               |       |          |
| 12     | 1   | TS000004R   | Grass-bag cover |               |               |       |          |
| 13     | 1   | TS000059R   | Frame           |               |               |       |          |
| 14     | 1   | TS000060R   | Cover           |               |               |       |          |
| 17     | 1   | TS000061R   | Frame           |               |               |       |          |
| 18     | 2   | TS000062R   | Bracket         |               |               |       |          |
| 19     | 1   | TS000381R   | Grass collector |               |               | Efco  |          |

www.agrodialog.ru



## изображение Mowing deck


| Ref.Nu | Qty | Part number | Description           | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-----------------------|---------------|---------------|-------|----------|
| 1      | 1   | TS000063R   | Belt cover            |               |               |       |          |
| 4      | 1   | TS000064R   | Bracket               |               |               |       |          |
| 5      | 1   | TS000065R   | Screw                 |               |               |       |          |
| 7      | 4   | TS000066R   | Clamp                 |               |               |       |          |
| 9      | 1   | TS000067R   | Spring                |               |               |       |          |
| 11     | 1   | TS000068R   | Nipple                |               |               |       |          |
| 12     | 1   | TS000069R   | Lever                 |               |               |       |          |
| 14     | 1   | TS000070R   | Bushing               |               |               |       |          |
| 15     | 2   | TS000071R   | Screw                 |               |               |       |          |
| 16     | 1   | TS000072R   | Pulley                |               |               |       |          |
| 17     | 1   | TS000073R   | Thrust bearing        |               |               |       |          |
| 18     | 2   | TS000074R   | Wheel                 |               |               |       |          |
| 21     | 1   | TS000075R   | Mowing deck           |               |               |       |          |
| 22     | 1   | TS000076R   | Bushing               |               |               |       |          |
| 24     | 2   | TS000005R   | Thrust bearing        |               |               |       |          |
| 25     | 2   | TS000006R   | Pulley                |               |               |       |          |
| 26     | 1   | TS000077R   | Screw                 |               |               |       |          |
| 27     | 1   | TS000078R   | Belt                  |               |               |       |          |
| 28     | 1   | TS000079R   | Bracket               |               |               |       |          |
| 29     | 1   | TS000080R   | Blade shaft           |               |               |       |          |
| 31     | 1   | TS000081R   | Screw                 |               |               |       |          |
| 32     | 2   | TS000082R   | Key                   |               |               |       |          |
| 33     | 2   | TS000083R   | Washer                |               |               |       |          |
| 36     | 2   | TS000084R   | Pulley                |               |               |       |          |
| 37     | 2   | TS000085R   | Disc (guard)          |               |               |       |          |
| 38     | 4   | TS000086R   | Thrust bearing        |               |               |       |          |
| 40     | 1   | TS000087R   | Blade shaft           |               |               |       |          |
| 41     | 1   | TS000088R   | Belt cover            |               |               |       |          |
| 42     | 2   | TS000089R   | Rivet                 |               |               |       |          |
| 44     | 2   | TS000090R   | Water hose connection |               |               |       |          |
| 45     | 2   | TS000091R   | Plate                 |               |               |       |          |
| 46     | 2   | TS000092R   | Tube                  |               |               |       |          |
| 47     | 2   | TS000093R   | Support               |               |               |       |          |
| 48     | 2   | TS000094R   | Spacer                |               |               |       |          |
| 50     | 2   | TS000095R   | Blade hub             |               |               |       |          |
| 51     | 1   | TS000096R   | Blade left            |               |               |       |          |
| 52     | 2   | TS000097R   | Washer                |               |               |       |          |
| 54     | 1   | TS000098R   | Screw                 |               |               |       |          |
| 55     | 2   | TS000099R   | Key                   |               |               |       |          |
| 56     | 1   | TS000100R   | Blade right           |               |               |       |          |



изображение Engine

| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes                                          | Bulletin |
|--------|-----|-------------|----------------|---------------|---------------|------------------------------------------------|----------|
| 1      | 1   | TS000147R   | Knob           |               |               |                                                |          |
| 4      | 1   | TS000008R   | Throttle cable |               |               |                                                |          |
| 7      | 1   | TS000009R   | Key            |               |               |                                                |          |
| 8      | 1   | TS000148R   | Pulley         |               |               | Motore 12,5 KM - Engine                        |          |
| 8      | 1   | TS000159R   | Pulley         |               |               | Motore 14,5 K / 16 K -<br>Engine 14,5 K / 16 K |          |
| 9      | 1   | TS000010R   | Support        |               |               |                                                |          |
| 11     | 1   | TS000149R   | Clutch         |               |               |                                                |          |
| 12     | 1   | TS000150R   | Bushing        |               |               |                                                |          |
| 13     | 1   | TS000151R   | Thickness      |               |               |                                                |          |
| 14     | 1   | TS000152R   | Bolt           |               |               |                                                |          |
| 15     | 1   | TS000153R   | Plate          |               |               |                                                |          |
| 17     | 1   | TS000154R   | Bracket        |               |               | Motore 12,5 KM - Engine                        |          |
| 17     | 1   | TS000160R   | Bracket        |               |               | Motore 14,5 K / 16 K -<br>Engine 14,5 K / 16 K |          |
| 19     | 1   | TS000155R   | Exhaust pipe   |               |               |                                                |          |
| 23     | 1   | TS000156R   | Gasket         |               |               |                                                |          |
| 24     | 1   | TS000157R   | Muffler        |               |               |                                                |          |
| 25     | 1   | TS000158R   | Support        |               |               |                                                |          |
| 29     | 1   | TS000011R   | Grid           |               |               |                                                |          |

www.agrodialog.ru




www.agrodialog.ru

изображение Tank

| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|-------|----------|
| 10     | 1   | TS000012R   | Filter      |               |               |       |          |
| 11     | 1   | TS000161R   | Tank        |               |               |       |          |
| 13     | 1   | TS000162R   | Band        |               |               |       |          |
| 14     | 1   | TS000163R   | Fuel hose   |               |               |       |          |
| 15     | 1   | TS000164R   | Band        |               |               |       |          |
| 16     | 1   | TS000013R   | Tank cap    |               |               |       |          |


www.agrodialog.ru



изображение Transmission


| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|----------------|---------------|---------------|-------|----------|
| 2      | 2   | TS000173R   | Bushing        |               |               |       |          |
| 3      | 1   | TS000253R   | Spacer         |               |               |       |          |
| 5      | 1   | TS000255R   | Support        |               |               |       |          |
| 6      | 1   | TS000130R   | Spring         |               |               |       |          |
| 8      | 1   | TS000122R   | Bushing        |               |               |       |          |
| 9      | 1   | TS000007R   | Pulley         |               |               |       |          |
| 11     | 1   | TS000006R   | Pulley         |               |               |       |          |
| 12     | 1   | TS000005R   | Thrust bearing |               |               |       |          |
| 16     | 1   | TS000263R   | Plate          |               |               |       |          |
| 20     | 1   | TS000259R   | Screw          |               |               |       |          |
| 21     | 1   | TS000025R   | Belt           |               |               |       |          |
| 23     | 3   | TS000023R   | Pulley         |               |               |       |          |
| 24     | 2   | TS000260R   | Bushing        |               |               |       |          |
| 27     | 1   | TS000264R   | Guide pulley   |               |               |       |          |

www.agrodialog.ru



## изображение Frame

| Ref.Nu | Qty | Part number | Description             | Validity from | Validity till | Notes          | Bulletin |
|--------|-----|-------------|-------------------------|---------------|---------------|----------------|----------|
| 2      | 1   | TS000165R   | Right footboard support |               |               |                |          |
| 4      | 1   | TS000166R   | Footrest pad            |               |               | Destra; Right  |          |
| 5      | 1   | TS000167R   | Right footboard cover   |               |               |                |          |
| 8      | 1   | TS000168R   | Right footboard support |               |               |                |          |
| 10     | 2   | TS000169R   | Bushing                 |               |               |                |          |
| 12     | 1   | TS000170R   | Frame                   |               |               |                |          |
| 13     | 1   | TS000171R   | Hood support            |               |               | Destra; Right  |          |
| 14     | 1   | TS000172R   | Support                 |               |               | Destra; Right  |          |
| 15     | 4   | TS000014R   | Washer                  |               |               |                |          |
| 16     | 1   | TS000015R   | Bumper                  |               |               |                |          |
| 17     | 4   | TS000173R   | Bushing                 |               |               |                |          |
| 18     | 1   | TS000016R   | Bumper                  |               |               |                |          |
| 19     | 1   | TS000017R   | Lower hood              |               |               |                |          |
| 22     | 1   | TS000174R   | Hood support            |               |               | Sinistra; Left |          |
| 23     | 1   | TS000175R   | Support                 |               |               | Sinistra; Left |          |
| 25     | 2   | TS000176R   | Plate                   |               |               |                |          |
| 26     | 1   | TS000177R   | Column support          |               |               |                |          |
| 28     | 1   | TS000178R   | Left footboard support  |               |               |                |          |
| 29     | 1   | TS000179R   | Footrest pad            |               |               | Sinistra; Left |          |
| 30     | 1   | TS000180R   | Left footboard cover    |               |               |                |          |
| 31     | 1   | TS000181R   | Frame                   |               |               |                |          |
| 32     | 2   | TS000182R   | Support                 |               |               |                |          |
| 33     | 1   | TS000183R   | Left footboard support  |               |               |                |          |
| 34     | 1   | TS000184R   | Support                 |               |               | Sinistra; Left |          |
| 35     | 2   | TS000185R   | Support                 |               |               |                |          |
| 36     | 1   | TS000186R   | Support                 |               |               | Destra; Right  |          |
| 37     | 1   | TS000187R   | Support                 |               |               | Sinistra; Left |          |
| 41     | 1   | TS000188R   | Support                 |               |               |                |          |
| 42     | 1   | TS000189R   | Bracket                 |               |               |                |          |
| 43     | 1   | TS000190R   | Hook                    |               |               | Sinistra; Left |          |
| 44     | 1   | TS000191R   | Hook                    |               |               | Destra; Right  |          |
| 45     | 2   | TS000192R   | Screw                   |               |               |                |          |
| 47     | 2   | TS000193R   | Spring                  |               |               |                |          |
| 48     | 1   | TS000194R   | Left bracket            |               |               |                |          |
| 49     | 1   | TS000195R   | Right bracket           |               |               |                |          |
| 51     | 1   | TS000196R   | Support                 |               |               | Destra; Right  |          |
| 52     | 1   | TS000197R   | Bracket                 |               |               |                |          |




[www.agrodialog.ru](http://www.agrodialog.ru)

изображение Front axle

| Ref.Nu | Qty | Part number | Description        | Validity from | Validity till | Notes          | Bulletin |
|--------|-----|-------------|--------------------|---------------|---------------|----------------|----------|
| 1      | 2   | TS000198R   | Hub cap            |               |               |                |          |
| 3      | 2   | TS000199R   | Washer             |               |               |                |          |
| 4      | 4   | TS000200R   | Spacer             |               |               |                |          |
| 5      | 2   | TS000018R   | Compl. front wheel |               |               |                |          |
| 5,4    | 4   | TS000204R   | Thrust bearing     |               |               |                |          |
| 6      | 1   | TS000019R   | Pin                |               |               | Destro; Right  |          |
| 8      | 4   | TS000020R   | Bushing            |               |               |                |          |
| 9      | 1   | TS000205R   | Front axle         |               |               |                |          |
| 11     | 1   | TS000021R   | Lever              |               |               |                |          |
| 12     | 2   | TS000083R   | Washer             |               |               |                |          |
| 17     | 1   | TS000206R   | Spacer             |               |               |                |          |
| 18     | 2   | TS000068R   | Nipple             |               |               |                |          |
| 21     | 1   | TS000022R   | Pin                |               |               | Sinistro; Left |          |


www.agrodialog.ru



www.agrodialog.ru

изображение Steering arm


| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes       | Bulletin |
|--------|-----|-------------|----------------|---------------|---------------|-------------|----------|
| 1      | 1   | TS000267R   | Joint          |               |               |             |          |
| 3      | 1   | TS000268R   | Tie rod        |               |               |             |          |
| 5      | 1   | TS000269R   | Plate          |               |               |             |          |
| 8      | 1   | TS000270R   | Sleeve         |               |               |             |          |
| 9      | 1   | TS000271R   | Bushing        |               |               |             |          |
| 10     | 1   | TS000272R   | Snap ring      |               |               |             |          |
| 11     | 1   | TS000273R   | Steering arm   |               |               |             |          |
| 13     | 2   | TS000274R   | Bushing        |               |               |             |          |
| 14     | 1   | TS000275R   | Tie rod        |               |               |             |          |
| 16     | 1   | TS000026R   | Sprocket       |               |               |             |          |
| 17     | 1   | TS000276R   | Pin            |               |               |             |          |
| 19     | 1   | TS000378R   | Bushing        |               |               |             |          |
| 20     | 1   | TS000277R   | Bushing        |               |               |             |          |
| 21     | 1   | TS000278R   | Cotter pin     |               |               |             |          |
| 22     | 1   | TS000279R   | Fixing plate   |               |               |             |          |
| 23     | 2   | TS000280R   | Bushing        |               |               |             |          |
| 24     | 1   | TS000027R   | Sector         |               |               |             |          |
| 25     | 1   | TS000281R   | Fixing plate   |               |               |             |          |
| 26     | 1   | TS000282R   | Joint          |               |               |             |          |
| 28     | 1   | TS000283R   | Spacer         |               |               |             |          |
| 30     | 1   | TS000284R   | Steering wheel |               |               |             |          |
| 31     | 1   | TS000028R   | Support        |               |               |             |          |
| 32     | 1   | TS000379R   | Washer         |               |               |             |          |
| 33     | 1   | TS000375R   | Cover          |               |               | Rosso - Red |          |



[www.agrodialog.ru](http://www.agrodialog.ru)

## изображение Rear axle


| Ref.Nu | Qty | Part number | Description       | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------------|---------------|---------------|-------|----------|
| 1      | 2   | TS000198R   | Hub cap           |               |               |       |          |
| 2      | 2   | TS000207R   | Snap ring         |               |               |       |          |
| 3      | 4   | TS000199R   | Washer            |               |               |       |          |
| 4      | 2   | TS000212R   | Compl. rear wheel |               |               |       |          |
| 5      | 2   | TS000210R   | Key               |               |               |       |          |
| 8      | 1   | TS000240R   | Plate             |               |               |       |          |
| 10     | 1   | TS000241R   | Transmission      |               |               |       |          |
| 11     | 1   | TS000242R   | Pin               |               |               |       |          |
| 15     | 1   | TS000243R   | Support           |               |               |       |          |
| 17     | 1   | TS000244R   | Break cable       |               |               |       |          |
| 18     | 1   | TS000245R   | Clamp cover rear  |               |               |       |          |
| 19     | 1   | TS000246R   | Pedal             |               |               |       |          |
| 23     | 1   | TS000247R   | Pin               |               |               |       |          |
| 25     | 1   | TS000248R   | Tie rod           |               |               |       |          |
| 27     | 1   | TS000249R   | Fixing plate      |               |               |       |          |
| 29     | 1   | TS000250R   | Spring            |               |               |       |          |
| 30     | 2   | TS000231R   | Support           |               |               |       |          |
| 32     | 1   | TS000230R   | Support           |               |               |       |          |
| 33     | 1   | TS000251R   | Clamp cover front |               |               |       |          |
| 37     | 1   | TS000232R   | Bushing           |               |               |       |          |
| 38     | 1   | TS000233R   | Compl.brake lever |               |               |       |          |
| 40     | 1   | TS000234R   | Control rod       |               |               |       |          |
| 41     | 1   | TS000235R   | Handle            |               |               |       |          |
| 42     | 1   | TS000236R   | Fork              |               |               |       |          |
| 43     | 1   | TS000237R   | Spring            |               |               |       |          |
| 44     | 1   | TS000238R   | Brake pedal       |               |               |       |          |
| 45     | 1   | TS000239R   | Cover moulding    |               |               |       |          |



изображение Seat

| Ref.Nu | Qty | Part number | Description  | Validity from | Validity till | Notes       | Bulletin |
|--------|-----|-------------|--------------|---------------|---------------|-------------|----------|
| 2      | 1   | TS000285R   | Bar          |               |               |             |          |
| 4      | 2   | TS000286R   | Spring       |               |               |             |          |
| 7      | 2   | TS000287R   | Cover        |               |               |             |          |
| 8      | 1   | TS000288R   | Seat support |               |               |             |          |
| 9      | 2   | TS000289R   | Screw        |               |               |             |          |
| 10     | 2   | TS000290R   | Slide        |               |               |             |          |
| 12     | 1   | TS000029R   | Seat switch  |               |               |             |          |
| 13     | 1   | TS000372R   | Seat         |               |               | Rosso - Red |          |
| 14     | 4   | TS000291R   | Spacer       |               |               |             |          |

www.agrodialog.ru




[www.agrodialog.ru](http://www.agrodialog.ru)

## изображение Cutting plate lifting

| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|-------|----------|
| 3      | 2   | TS000292R   | Rod         |               |               |       |          |
| 4      | 1   | TS000293R   | Tie rod     |               |               |       |          |
| 6      | 1   | TS000294R   | Joint       |               |               |       |          |
| 10     | 1   | TS000295R   | Rod         |               |               |       |          |
| 11     | 1   | TS000296R   | Axel lift   |               |               |       |          |
| 12     | 1   | TS000297R   | Rod         |               |               |       |          |
| 13     | 1   | TS000298R   | Support     |               |               |       |          |
| 15     | 4   | TS000231R   | Support     |               |               |       |          |
| 16     | 2   | TS000299R   | Joint       |               |               |       |          |
| 17     | 1   | TS000300R   | Rod         |               |               |       |          |
| 19     | 1   | TS000301R   | Plate       |               |               |       |          |
| 20     | 1   | TS000226R   | Knob        |               |               |       |          |
| 21     | 1   | TS000030R   | Support     |               |               |       |          |
| 22     | 1   | TS000302R   | Spring      |               |               |       |          |
| 25     | 1   | TS000303R   | Spring      |               |               |       |          |
| 26     | 1   | TS000031R   | Lever       |               |               |       |          |
| 27     | 1   | TS000223R   | Snap ring   |               |               |       |          |
| 28     | 2   | TS000378R   | Bushing     |               |               |       |          |
| 29     | 1   | TS000304R   | Lever       |               |               |       |          |
| 30     | 1   | TS000305R   | Tie rod     |               |               |       |          |
| 31     | 1   | TS000306R   | Tie rod     |               |               |       |          |
| 32     | 1   | TS000307R   | Joint       |               |               |       |          |


www.agrodialog.ru



[www.agrodialog.ru](http://www.agrodialog.ru)


## изображение Electrical parts

| Ref.Nu | Qty | Part number | Description       | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------------|---------------|---------------|-------|----------|
| 1      | 1   | TS000314R   | Battery cables    |               |               |       |          |
| 2      | 1   | TS000335R   | Wiring            |               |               |       |          |
| 3      | 20  | TS000316R   | Band              |               |               |       |          |
| 3      | 5   | TS000317R   | Band              |               |               |       |          |
| 4      | 1   | TS000318R   | Switch protection |               |               |       |          |
| 5      | 1   | TS000032R   | Switch            |               |               |       |          |
| 6      | 1   | TS000319R   | Battery cables    |               |               |       |          |
| 7      | 1   | TS000320R   | Indicator         |               |               |       |          |
| 8      | 1   | TS000321R   | Snap ring         |               |               |       |          |
| 10     | 1   | TS000033R   | Solenoid          |               |               |       |          |
| 13     | 1   | TS000323R   | Clamp             |               |               |       |          |
| 15     | 1   | TS000324R   | Wire              |               |               |       |          |
| 16     | 1   | TS000325R   | Fuse              |               |               |       |          |
| 17     | 1   | TS000034R   | Switch            |               |               |       |          |
| 18     | 1   | TS000326R   | Switch            |               |               |       |          |
| 19     | 1   | TS000035R   | Shoe              |               |               |       |          |
| 20     | 1   | TS000327R   | Bracket           |               |               |       |          |
| 21     | 2   | TS000036R   | Micro-switch      |               |               |       |          |
| 26     | 1   | TS000328R   | Fixing plate      |               |               |       |          |
| 29     | 1   | TS000329R   | Lever             |               |               |       |          |
| 30     | 1   | TS000330R   | Lever             |               |               |       |          |
| 34     | 2   | TS000331R   | Switch            |               |               |       |          |
| 35     | 1   | TS000332R   | Belt              |               |               |       |          |
| 36     | 1   | TS000038R   | Battery           |               |               |       |          |
| 37     | 2   | TS000333R   | Bracket           |               |               |       |          |
| 39     | 1   | TS000336R   | Control lever     |               |               |       |          |
| 40     | 1   | TS000337R   | Bracket           |               |               |       |          |
| 41     | 2   | TS000037R   | Micro-switch      |               |               |       |          |
| 43     | 1   | TS000338R   | Support           |               |               |       |          |



www.agrodialog.ru


| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes       | Bulletin |
|--------|-----|-------------|----------------|---------------|---------------|-------------|----------|
| 1      | 1   | TS000340R   | Wiring         |               |               |             |          |
| 2      | 1   | TS000341R   | Adapter        |               |               |             |          |
| 3      | 1   | TS000342R   | Deflector      |               |               |             |          |
| 4      | 1   | TS000343R   | Right guard    |               |               |             |          |
| 6      | 5   | TS000344R   | Fairled        |               |               |             |          |
| 7      | 1   | TS000360R   | Right guard    |               |               | Rosso - Red |          |
| 10     | 2   | TS000345R   | Pin            |               |               |             |          |
| 11     | 1   | TS000346R   | Headlamp       |               |               |             |          |
| 12     | 1   | TS000363R   | Guard          |               |               | Rosso - Red |          |
| 13     | 1   | TS000039R   | Upper hood     |               |               |             |          |
| 14     | 1   | TS000347R   | Headlamp       |               |               |             |          |
| 15     | 1   | TS000366R   | Engine cover   |               |               | Rosso - Red |          |
| 16     | 1   | TS000369R   | Left guard     |               |               | Rosso - Red |          |
| 17     | 1   | TS000348R   | Left guard     |               |               |             |          |
| 19     | 1   | TS000349R   | Cover          |               |               |             |          |
| 20     | 4   | TS000350R   | Shock absorber |               |               |             |          |
| 22     | 1   | TS000351R   | Dashboard      |               |               |             |          |
| 23     | 15  | TS000066R   | Clamp          |               |               |             |          |
| 24     | 1   | TS000352R   | Panel          |               |               |             |          |
| 25     | 1   | TS000040R   | Cover          |               |               |             |          |
| 27     | 1   | TS000353R   | Housing        |               |               |             |          |
| 28     | 1   | TS000041R   | Wheels cover   |               |               |             |          |
| 30     | 1   | TS000354R   | Housing        |               |               |             |          |
| 31     | 1   | TS000355R   | Panel          |               |               |             |          |
| 34     | 1   | TS000357R   | Lock           |               |               |             |          |



[www.agrodialog.ru](http://www.agrodialog.ru)

| Ref.Nu | Qty | Part number | Description  | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|--------------|---------------|---------------|-------|----------|
| 2      | 1   | TS000358R   | Towing hitch |               |               |       |          |
| 3      | 2   | TS000359R   | Spacer       |               |               |       |          |


www.agrodialog.ru



[www.agrodialog.ru](http://www.agrodialog.ru)

| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes           | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|-----------------|----------|
| 1      | 1   | TS000405R   | Label       |               |               |                 |          |
| 2      | 1   | TS000396R   | Label       |               |               |                 |          |
| 3      | 1   | TS000385R   | Label       |               |               | 86R/14,5K       |          |
| 4      | 1   | TS000399R   | Label       |               |               | Destro - Right  |          |
| 4      | 1   | TS000400R   | Label       |               |               | Sinistro - Left |          |

www.agrodialog.ru




## изображение Starter, carburettor and air filter

| Ref.Nu | Qty | Part number   | Description            | Validity from | Validity till | Notes | Bulletin |
|--------|-----|---------------|------------------------|---------------|---------------|-------|----------|
| 1      | 1   | G118551261E0  | Cover                  |               |               |       |          |
| 2      | 3   | G112790500E0  | Screw                  |               |               |       |          |
| 3      | 1   | G118550203E0  | Fan cover              |               |               |       |          |
| 4      | 3   | G118551280E0  | Plate                  |               |               |       |          |
| 5      | 4   | G112791213E1  | Screw                  |               |               |       |          |
| 6      | 1   | G118550237E0  | Nut                    |               |               |       |          |
| 7      | 1   | G118550236E0  | Starter cup            |               |               |       |          |
| 8      | 1   | G118550235E1  | Flywheel fan           |               |               |       |          |
| 9      | 1   | G118550234E2  | Flywheel assy          |               |               |       |          |
| 10     | 1   | G118552635E0R | Start motor assy       |               |               |       |          |
| 11     | 2   | G112691100E0  | Screw                  |               |               |       |          |
| 12     | 1   | G118551441E0  | Coil assy, charge      |               |               |       |          |
| 13     | 1   | G118551438E0  | Ignition coil          |               |               |       |          |
| 15     | 1   | 3055122R      | Spark plug             |               |               |       |          |
| 16     | 1   | G118551428E1  | Governor               |               |               |       |          |
| 17     | 1   | G118551439E0  | Cable                  |               |               |       |          |
| 18     | 1   | G118550331E1  | Remote control assy    |               |               |       |          |
| 19     | 1   | G118550212E0  | Fairled                |               |               |       |          |
| 20     | 1   | G118550213E0  | Spring                 |               |               |       |          |
| 21     | 1   | G118551219E0  | Rod                    |               |               |       |          |
| 22     | 1   | G118551218E0  | Rod                    |               |               |       |          |
| 23     | 1   | G118551267E0  | Bracket                |               |               |       |          |
| 24     | 1   | G118551221E0  | Throttle rod           |               |               |       |          |
| 25     | 2   | G118551277E0  | Screw                  |               |               |       |          |
| 26     | 1   | G118551520E0  | Carburetor             |               |               |       |          |
| 27     | 1   | G118550225E1  | Breather fuel pipe     |               |               |       |          |
| 28     | 1   | G118551516E0R | Air filter kit         |               |               |       |          |
| 29     | 2   | G118550201E0  | Knob                   |               |               |       |          |
| 30     | 1   | G118550200E0  | Air filter cover       |               |               |       |          |
| 31     | 1   | G118550199E0R | Air filter             |               |               |       |          |
| 32     | 1   | G118550762E0  | Gasket                 |               |               |       |          |
| 33     | 2   | G112154510E0  | Nut                    |               |               |       |          |
| 34     | 1   | G118550432E0  | Fuel pipe              |               |               |       |          |
| 35     | 1   | G118550427E0  | Fuel filer             |               |               |       |          |
| 36     | 2   | G118551279E0  | Stud                   |               |               |       |          |
| 37     | 1   | G118551263E0  | Gasket                 |               |               |       |          |
| 38     | 1   | G118551265E0  | Insulator              |               |               |       |          |
| 39     | 2   | G118551262E0  | Gasket                 |               |               |       |          |
| 40     | 1   | G118551259E0  | Guard                  |               |               |       |          |
| 42     | 1   | G118551260E0  | Guard                  |               |               |       |          |
| 45     | 1   | G118550365E1  | Repair kit             |               |               |       |          |
| 46     | 1   | G118550332E1  | Brush                  |               |               |       |          |
| 47     | 1   | G118550440E0  | Repair kit             |               |               |       |          |
| 48     | 1   | G118550442E0  | Carburettor gasket set |               |               |       |          |

| Ref.Nu | Qty | Part number  | Description    | Validity from | Validity till | Notes | Bulletin |
|--------|-----|--------------|----------------|---------------|---------------|-------|----------|
| 51     | 1   | G118550451E1 | Complete motor |               |               |       |          |

www.agrodialog.ru



## изображение Engine assy

| Ref.Nu | Qty | Part number  | Description         | Validity from | Validity till | Notes | Bulletin |
|--------|-----|--------------|---------------------|---------------|---------------|-------|----------|
| 1      | 1   | G118551418E0 | Oil seal            |               |               |       |          |
| 2      | 1   | G118551224E0 | Crankcase           |               |               |       |          |
| 3      | 1   | G118551227E0 | Cover               |               |               |       |          |
| 4      | 1   | G118551229E0 | Gasket              |               |               |       |          |
| 5      | 1   | G118550303E0 | Breather valve      |               |               |       |          |
| 6      | 2   | G118551284E0 | Bearing             |               |               |       |          |
| 7      | 1   | G118551242E0 | Counterweight (red) |               |               |       |          |
| 8      | 1   | G118551243E0 | Counterweight (red) |               |               |       |          |
| 9      | 2   | G118551282E0 | Washer              |               |               |       |          |
| 10     | 1   | G118551286E0 | O-ring              |               |               |       |          |
| 11     | 2   | G118550227E0 | Bearing             |               |               |       |          |
| 12     | 1   | G118550232E0 | Crankshaft set      |               |               |       |          |
| 13     | 1   | G118550288E0 | Key                 |               |               |       |          |
| 14     | 1   | G118550231E1 | Connecting rod      |               |               |       |          |
| 15     | 2   | G118551283E0 | Ring                |               |               |       |          |
| 16     | 1   | G118551241E0 | Piston pin          |               |               |       |          |
| 17     | 1   | G118551519E0 | Piston              |               |               |       |          |
| 18     | 1   | G118551518E0 | Piston ring set     |               |               |       |          |
| 19     | 1   | G118550243E0 | Camshaft assy       |               |               |       |          |
| 20     | 2   | G118551252E0 | Valve               |               |               |       |          |
| 21     | 2   | G118550242E1 | Push rods assy      |               |               |       |          |
| 22     | 1   | G118550347E0 | Governor assy       |               |               |       |          |
| 23     | 1   | G118551268E0 | Rod                 |               |               |       |          |
| 25     | 1   | G118551285E0 | Oil seal            |               |               |       |          |
| 26     | 1   | G118550856E0 | Fork                |               |               |       |          |
| 27     | 1   | G118551220E0 | Arm assy            |               |               |       |          |
| 28     | 1   | G118550805E0 | Screw               |               |               |       |          |
| 29     | 1   | G118550806E0 | Nut                 |               |               |       |          |
| 30     | 1   | G118550355E1 | Gasket              |               |               |       |          |
| 31     | 1   | G118551258E0 | Buffer              |               |               |       |          |
| 32     | 1   | G118551257E1 | Cover               |               |               |       |          |
| 34     | 1   | G118551256E1 | Oil filter          |               |               |       |          |
| 35     | 1   | G118551207E0 | Crankcase cover     |               |               |       |          |
| 36     | 1   | G118551418E0 | Oil seal            |               |               |       |          |
| 37     | 4   | G112691115E0 | Screw               |               |               |       |          |
| 40     | 1   | G118550224E1 | Oil pump            |               |               |       |          |
| 41     | 1   | G118551287E0 | Gasket              |               |               |       |          |
| 42     | 1   | G118550223E0 | Oil pump cover      |               |               |       |          |
| 43     | 1   | G118550205E2 | Oil filler assy     |               |               |       |          |
| 44     | 1   | G112674701E0 | Screw               |               |               |       |          |
| 45     | 1   | G118551230E0 | Ring                |               |               |       |          |
| 46     | 1   | G118551228E0 | Cover               |               |               |       |          |
| 51     | 1   | G118551232E0 | Gasket              |               |               |       |          |
| 52     | 1   | 68050044     | Cylinder head       |               |               |       |          |

## изображение Engine assy

| Ref.Nu | Qty | Part number  | Description                | Validity from    | Validity till | Notes | Bulletin      |
|--------|-----|--------------|----------------------------|------------------|---------------|-------|---------------|
| 53     | 1   | G118551289E0 | Suction/delivery valve kit |                  |               |       |               |
| 54     | 2   | G118551245E0 | Slide                      |                  |               |       |               |
| 55     | 2   | G118551248E0 | Gasket                     |                  |               |       |               |
| 56     | 2   | G118550529E0 | Valves spring              |                  |               |       |               |
| 57     | 4   | G118551247E0 | Valve                      |                  |               |       |               |
| 58     | 2   | G118551246E0 | Slide                      |                  |               |       |               |
| 59     | 2   | G118551244E0 | Cap                        |                  |               |       |               |
| 60     | 1   | G118551254E0 | Plate                      |                  |               |       |               |
| 61     | 1   | G118551249E0 | Compensator                |                  |               |       |               |
| 62     | 4   | G118551278E0 | Screw                      |                  |               |       |               |
| 63     | 1   | L66151483    | Set cover                  | Settembre 2019 / |               |       | BT8-020-04/20 |
| 64     | 1   | G118551534E0 | Cover                      | September 2019 / |               |       | BT8-020-04/20 |
| 65     | 4   | L66151483    | Set cover                  | Settembre 2019 / |               |       | BT8-020-04/20 |
| 66     | 1   | G118551272E0 | Gasket                     | September 2019   |               |       |               |

www.agrodialog.ru