


EF 92R/19 K V Cat. 2025 Garden tractor



Документы

[Mulching Kit](#)[Grassbag](#)[Engine](#)[Mowing deck](#)[Tank](#)[Transmission](#)[Frame](#)[Front axle](#)[Steering arm](#)[Rear axle](#)[Seat](#)[Cutting plate lifting](#)[Electrical parts](#)[body](#)[Towing hitch](#)

www.agrodialog.ru




www.agrodialog.ru

изображение Mulching Kit

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000047R	Knob				
2	2	TS000048R	Spring				
3	1	TS000049R	Handle				
4	1	TS000050R	Spring				
5	1	TS000051R	Pin				
6	1	TS000002R	Deflector				


www.agrodialog.ru



изображение Grassbag

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	1	TS000052R	Exhaust				
5	1	TS000053R	Exhaust pipe				
6	2	TS000054R	Screw				
7	1	TS000055R	Cap				
9	1	TS000056R	Knob				
10	1	TS000057R	Lever				
11	1	TS000058R	Gasket				
12	1	TS000004R	Grass-bag cover				
13	1	TS000413R	Frame				
14	1	TS000060R	Cover				
17	1	TS000061R	Frame				
18	2	TS000062R	Bracket				
19	1	TS000381R	Grass collector			Efco	


www.agrodialog.ru



изображение Engine


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000147R	Knob				
4	1	TS000430R	Throttle cable				
7	1	TS000009R	Key				
8	1	TS000159R	Pulley			Motore 14,5 K / 16 K / 19	
10	1	TS000010R	Support				
12	1	TS000149R	Clutch				
13	1	TS000150R	Bushing				
14	1	TS000151R	Thickness				
15	1	TS000152R	Bolt				
16	1	TS000153R	Plate				
18	1	TS000436R	Bracket				
23	1	TS000431R	Muffler			Motore 14,5 K / 16 K /19	
24	2	TS000156R	Gasket				
25	1	TS000432R	Grid				
29	1	TS000158R	Support				

www.agrodialog.ru



изображение Mowing deck


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000101R	Belt cover				
4	1	TS000064R	Bracket				
5	1	TS000065R	Screw				
7	4	TS000066R	Clamp				
9	1	TS000067R	Spring				
11	1	TS000068R	Nipple				
12	1	TS000069R	Lever				
14	1	TS000070R	Bushing				
15	2	TS000071R	Screw				
16	1	TS000072R	Pulley				
17	1	TS000073R	Thrust bearing				
18	2	TS000074R	Wheel				
21	1	TS000102R	Mowing deck				
22	1	TS000076R	Bushing				
24	2	TS000005R	Thrust bearing				
25	2	TS000006R	Pulley				
26	1	TS000077R	Screw				
27	1	TS000103R	Belt				
28	1	TS000079R	Bracket				
29	2	TS000090R	Water hose connection				
31	2	TS000089R	Rivet				
32	1	TS000080R	Blade shaft				
33	4	TS000086R	Thrust bearing				
34	2	TS000085R	Disc (guard)				
35	2	TS000084R	Pulley				
36	2	TS000082R	Key				
40	1	TS000081R	Screw				
41	1	TS000087R	Blade shaft				
44	1	TS000105R	Belt cover				
45	2	TS000091R	Plate				
46	2	TS000092R	Tube				
47	2	TS000093R	Support				
48	2	TS000094R	Spacer				
50	2	TS000095R	Blade hub				
51	1	TS000106R	Blade left				
52	2	TS000097R	Washer				
54	1	TS000098R	Screw				
55	2	TS000099R	Key				
56	1	TS000107R	Blade right				
57	1	TS000408R	Screw				



www.agrodialog.ru

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
10	1	TS000012R	Filter				
11	1	TS000161R	Tank				
13	2	TS000162R	Band				
14	1	TS000163R	Fuel hose				
16	1	TS000013R	Tank cap				


www.agrodialog.ru



изображение Transmission


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	2	TS000173R	Bushing				
3	1	TS000253R	Spacer				
5	1	TS000255R	Support				
6	1	TS000130R	Spring				
8	1	TS000122R	Bushing				
9	1	TS000007R	Pulley				
11	1	TS000006R	Pulley				
12	1	TS000005R	Thrust bearing				
16	1	TS000263R	Plate				
20	1	TS000259R	Screw				
21	1	TS000025R	Belt				
23	3	TS000023R	Pulley				
24	2	TS000260R	Bushing				
27	1	TS000264R	Guide pulley				

www.agrodialog.ru



изображение Frame

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	1	TS000165R	Right footboard support				
4	1	TS000166R	Footrest pad			Destra; Right	
5	1	TS000167R	Right footboard cover				
8	1	TS000168R	Right footboard support				
10	2	TS000169R	Bushing				
12	1	TS000170R	Frame				
13	1	TS000171R	Hood support			Destra; Right	
14	1	TS000172R	Support			Destra; Right	
15	4	TS000014R	Washer				
16	1	TS000015R	Bumper				
17	4	TS000173R	Bushing				
18	1	TS000016R	Bumper				
19	1	TS000017R	Lower hood				
22	1	TS000174R	Hood support			Sinistra; Left	
23	1	TS000175R	Support			Sinistra; Left	
25	2	TS000176R	Plate				
26	1	TS000177R	Column support				
28	1	TS000178R	Left footboard support				
29	1	TS000179R	Footrest pad			Sinistra; Left	
30	1	TS000180R	Left footboard cover				
31	1	TS000181R	Frame				
32	2	TS000182R	Support				
33	1	TS000183R	Left footboard support				
34	1	TS000184R	Support			Sinistra; Left	
35	2	TS000185R	Support				
36	1	TS000186R	Support			Destra; Right	
37	1	TS000187R	Support			Sinistra; Left	
41	1	TS000416R	Support				
42	1	TS000189R	Bracket				
43	1	TS000190R	Hook			Sinistra; Left	
44	1	TS000191R	Hook			Destra; Right	
45	2	TS000192R	Screw				
47	2	TS000193R	Spring				
48	1	TS000194R	Left bracket				
49	1	TS000195R	Right bracket				
51	1	TS000196R	Support			Destra; Right	
52	1	TS000197R	Bracket				




www.agrodialog.ru

изображение Front axle

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	TS000198R	Hub cap				
3	2	TS000199R	Washer				
4	4	TS000200R	Spacer				
5	2	TS000018R	Compl. front wheel				
5.4	4	TS000204R	Thrust bearing				
6	1	TS000019R	Pin			Destro; Right	
8	4	TS000020R	Bushing				
9	1	TS000205R	Front axle				
11	1	TS000021R	Lever				
17	1	TS000206R	Spacer				
18	2	TS000068R	Nipple				
21	1	TS000022R	Pin			Sinistro; Left	


www.agrodialog.ru



www.agrodialog.ru

изображение Steering arm


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000267R	Joint				
3	1	TS000268R	Tie rod				
5	1	TS000269R	Plate				
8	1	TS000270R	Sleeve				
9	1	TS000271R	Bushing				
10	1	TS000272R	Snap ring				
11	1	TS000273R	Steering arm				
13	2	TS000274R	Bushing				
14	1	TS000275R	Tie rod				
16	1	TS000026R	Sprocket				
17	1	TS000276R	Pin				
19	1	TS000378R	Bushing				
20	1	TS000277R	Bushing				
21	1	TS000278R	Cotter pin				
22	1	TS000279R	Fixing plate				
23	2	TS000280R	Bushing				
24	1	TS000027R	Sector				
25	1	TS000281R	Fixing plate				
26	1	TS000282R	Joint				
28	1	TS000283R	Spacer				
30	1	TS000284R	Steering wheel				
31	1	TS000028R	Support				
32	1	TS000379R	Washer				
33	1	TS000375R	Cover			Rosso - Red	



www.agrodialog.ru

изображение Rear axle


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	TS000198R	Hub cap				
2	2	TS000207R	Snap ring				
3	4	TS000199R	Washer				
4	2	TS000212R	Compl. rear wheel				
5	2	TS000210R	Key				
8	1	TS000240R	Plate				
10	1	TS000241R	Transmission				
11	1	TS000242R	Pin				
15	1	TS000243R	Support				
17	1	TS000244R	Break cable				
18	1	TS000245R	Clamp cover rear				
19	1	TS000246R	Pedal				
23	1	TS000247R	Pin				
25	1	TS000248R	Tie rod				
27	1	TS000249R	Fixing plate				
29	1	TS000250R	Spring				
30	2	TS000231R	Support				
32	1	TS000230R	Support				
33	1	TS000251R	Clamp cover front				
37	1	TS000232R	Bushing				
38	1	TS000233R	Compl.brake lever				
40	1	TS000234R	Control rod				
41	1	TS000235R	Handle				
42	1	TS000236R	Fork				
43	1	TS000237R	Spring				
44	1	TS000439R	Brake pedal				
45	1	TS000239R	Cover moulding				



изображение Seat

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	1	TS000285R	Bar				
4	2	TS000286R	Spring				
7	2	TS000287R	Cover				
8	1	TS000418R	Seat support				
9	2	TS000289R	Screw				
10	2	TS000290R	Slide				
12	1	TS000029R	Seat switch				
13	1	TS000372R	Seat			Rosso - Red	
14	4	TS000291R	Spacer				

www.agrodialog.ru




www.agrodialog.ru

изображение Cutting plate lifting

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
3	2	TS000292R	Rod				
4	1	TS000293R	Tie rod				
6	1	TS000294R	Joint				
10	1	TS000295R	Rod				
11	1	TS000296R	Axel lift				
12	1	TS000297R	Rod				
13	1	TS000298R	Support				
15	4	TS000231R	Support				
16	2	TS000299R	Joint				
17	1	TS000300R	Rod				
19	1	TS000301R	Plate				
20	1	TS000226R	Knob				
21	1	TS000030R	Support				
22	1	TS000302R	Spring				
25	1	TS000303R	Spring				
26	1	TS000031R	Lever				
27	1	TS000223R	Snap ring				
28	2	TS000378R	Bushing				
29	1	TS000304R	Lever				
30	1	TS000305R	Tie rod				
31	1	TS000306R	Tie rod				
32	1	TS000307R	Joint				


www.agrodialog.ru



www.agrodialog.ru

изображение Electrical parts

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000314R	Battery cables				
2	1	TS000440R	Wiring				
3	20	TS000316R	Band				
3	2	TS000317R	Band				
4	1	TS000319R	Battery cables				
5	1	TS000032R	Switch				
6	1	TS000320R	Indicator				
7	1	TS000321R	Snap ring				
9	1	TS000033R	Solenoid				
12	1	TS000323R	Clamp				
14	1	TS000324R	Wire				
15	1	TS000325R	Fuse				
16	1	TS000034R	Switch				
17	1	TS000326R	Switch				
18	1	TS000035R	Shoe				
19	1	TS000327R	Bracket				
20	2	TS000036R	Micro-switch				
25	1	TS000328R	Fixing plate				
28	1	TS000329R	Lever				
29	1	TS000330R	Lever				
33	1	TS000331R	Switch				
34	1	TS000332R	Belt				
35	1	TS000038R	Battery				
36	2	TS000333R	Bracket				
38	1	TS000336R	Control lever				
39	1	TS000037R	Micro-switch				
40	1	TS000337R	Bracket				
41	1	TS000435R	Switch				
43	1	68050054	Support + switch kit				
44	1	TS000318R	Switch protection				
45	1	68130481	Battery charger				
46	1	TS000412R	Starting key				




www.agrodialog.ru

изображение body

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000340R	Wiring				
2	1	TS000341R	Adapter				
3	1	TS000342R	Deflector				
4	1	TS000343R	Right guard				
6	5	TS000344R	Fairled				
7	1	TS000360R	Right guard			Rosso - Red	
10	2	TS000345R	Pin				
11	1	TS000441R	Headlamp				
12	1	TS000363R	Guard			Rosso - Red	
13	1	TS000039R	Upper hood				
14	1	TS000442R	Headlamp				
15	1	TS000366R	Engine cover			Rosso - Red	
16	1	TS000369R	Left guard			Rosso - Red	
17	1	TS000348R	Left guard				
19	1	TS000349R	Cover				
20	4	TS000350R	Shock absorber				
22	1	TS000351R	Dashboard				
23	15	TS000066R	Clamp				
24	1	TS000352R	Panel				
25	1	TS000040R	Cover				
27	1	TS000353R	Housing				
28	1	TS000041R	Wheels cover				
30	1	TS000354R	Housing				
31	1	TS000355R	Panel				

www.agrodialog.ru



www.agrodialog.ru

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	1	TS000358R	Towing hitch				
3	2	TS000359R	Spacer				

www.agrodialog.ru